


## **Tech Display**

# **QUICK START GUIDE**

## **Controls and Functions**







#### How to connect

Connect V1 to "MAIN", Tech Display to "ACC".

#### How to set muted volume

To set the sound level you will hear after muting, tap or to display the main volume in the Bogey Counter (0-9); the mute icon will be off. Tap the Control Button; the mute icon will turn on and the Bogey Counter will show muted volume (0-9). Press or until the muted volume reaches the desired level.

# How to save an alert to memory

During an alert, press-and-hold V1 Button for 1.5 seconds.

# How to recall an alert from memory

When no alert is present, tap the V1 Button. The most recent priority alert will be shown.

- To recall the first (newest) saved alert, tap .
- To recall the last (oldest) saved alert, tap ⊕ twice. The Tech Display version will show after the first tap.

#### **Control Button**

- Changing modes: Pressand-hold repeatedly to step through the three available Analyzer Modes.
- Muting: Tap during an alert.

#### **V1 Button**

- Tap when no alert is active to activate Recall Mode.
- To save an active alert, press-and-hold 1.5 seconds.
- To cycle through display modes 1, 2, and 3, double- click to step through the following grid:

Display Mode	Detector Display	Tech Display
1 (default)	OFF	ON
2	ON	OFF
3	ON	ON

#### **Recall Mode**

- Tap V1 Button when no alert is active to activate Recall Mode.
- The most recent priority alert will be shown if it exists. Indicated by —.
- At the end of the saved alerts, the most recent priority alert and the Tech Display version will be shown.
- Continue tapping to go through the list again.

#### Volume +, Volume -

- Press-and-hold to raise or lower initial volume. Sound level 0-9 temporarily indicated in the Bogey Counter. A quick press on either button shows current volume setting.
- Changing the volume is not available on V1 Gen1.

#### **Bogey Counter**

### **Normal Operation**

Blank - Power off All others - Same as V1

#### **Recall Mode**

**P** - Priority Alert

123 etc. - Memory Index

#### **Radar Locator**







Radar ahead Radar b


Radar behind

NOTE: In the case of multiple bogeys from different directions, an arrow will glow for each direction. The most urgent, or primary, threat will be indicated by a blinking arrow.

### **Frequency Display**

Shows frequency of a current alert or a priority alert recalled from memory.

## **Frequencies that Matter**



<sup>\*</sup>As police radar guns age or lose calibration, their frequency may drift out of the expected ranges shown.

NOTE: To assure you're getting full functionality from the Tech Display, use *V1 Connection, the app* to make sure you have the latest firmware version for V1 Gen2.

WARNING: WATCHING THE SCREEN WHILE YOUR VEHICLE IS IN MOTION MAY BE DANGEROUS. DRIVE SAFELY AND OBEY ALL TRAFFIC LAWS.



Valentine Research

10280 Alliance Road Cincinnati, OH 45242 (513) 984-8900 1- (800) 331-3030

www.valentine1.com